



Precision Springs For Superior Handling

**Directions for trimming the Bump Stop**

1. Please measure the stock height of your vehicle from the center of the axle hub to the fender before proceeding, so you do not have any discrepancies. Some vehicles are uneven prior to installation.
2. Driver Front \_\_\_\_\_ Driver Rear \_\_\_\_\_
3. Passenger Front \_\_\_\_\_ Passenger Rear \_\_\_\_\_
4. Remove original spring from strut. ( *CAUTION !!! You must use a spring compressor to remove the load that is on the spring in strut assembly. Failure to do this may result in injury or death*).
5. When spring is free from strut, remove bump stop from under the dust boot.
6. Trim approximately  $\frac{1}{2}$  to  $\frac{3}{4}$  from bottom of Bump Stop leaving top to be reinstalled.



7. Reassemble Bump Stop, Strut and spring, then reattach to vehicle.

**Note : Bump stops may vary from the model pictured above.**